
Step 1: If you print this page, measure if the dimensions have been correctly printed


Step 2: Prepare the reed switch

- 1. Use reed switch with glas diameter 1.8 mm and glas length 10 mm
- 2. Ensure the correct orientation of the reed switch
- 3. With needle-nose pliers bend the reed's leads 90°, distance 16 mm
- 4. Cut leads at 10 mm



Step 3: Prepare the cable

- 1. Cable must have at least 2 wires
- 2. Cable diameter up to 3 mm
- 3. Cable length: your choice
- 4. Cut first wire at 10 mm and second wire at 25 mm
- 5. Insert cable into housing



Step 4: Solder reed switch leads and cable wires

Step 5: Fix the cable using a zip tie (width = 3mm, height = 1mm)

Step 6: Press-fit the cover



Printables: https://www.printables.com/model/308913-gas-metering-device-sensor-housing-for-reed-switch

Thingiverse: https://www.thingiverse.com/thing:5603875

GitHub: https://github.com/JurgenO/GasMetering



